

```

1  '''
2  ### Information for use of AddTextToDXF ###
3
4  @author Hans-Christian Ringstad
5
6  This script was made to be used in the Bachelor Thesis
   Manulab spring 2020, it will put a Logo image and a text on
   a
7  dxf-file template. Files used in this program needs to be
   put in the same folder as the program. For the source code
8  Python 3.8.1 was used.
9
10 ### Files needed to run the program ###
11 info.csv: Contains information for the program to add text
   and Logo image. This csv-file uses ";" as separator and the
12         program will only read the info in the last row.
13         This file will need to contain these fields;
14         # Name of field # Datatype # Comment
15         finalFileName      : String      : Name of the dxf file that
   will be created
16         templateName       : String      : Name of the template to be
   used as background
17         LogoFileName        : String      : Name of the Logo PNG-file
18         xInsertPointLogo: float      : x-coordinate of the insert
   point of Logo, the insertion point will be at the bottom
   right
19         yInsertPointLogo: float      : y-coordinate of the insert
   point of Logo, the insertion point will be at the bottom
   right
20         xPixelSize          : int        : x length in pixels
21         yPixelSize          : int        : y length in pixels
22         xSizeInmm           : float      : x length in millimeter
23         ySizeInmm           : float      : y length in millimeter
24         rotationLogo        : float      : Rotation of Logo
25         textToInsert        : String      : Text to insert on the dxf
   file
26         textStyle           : String      : Text style
27         xInsertPointText: float      : x-coordinate of the insert
   point of text, the insertion point will be at the top
   center
28         yInsertPointText: float      : y-coordinate of the insert
   point of text, the insertion point will be at the top
   center
29         rotationText        : float      : Rotation of text
30         alignmentText       : int        : Alignement for the text*
31         textWidth           : float      : Width of text fields, does

```

```

31 not cut individual words
32     textHeight      : float      : Height of text
33     #                #                #
34 *See doc for more info: https://ezdxf.mozman.at/docs/dxfentities/mtext.html#ezdxf.entities.MText.dxf.attachment\_point
35
36 templateName.dxf: The file containing the dxf template to
    be used by the program, the name of the file is to be
    decided
37
38
39 LogoFileName.png: The file containing the the png of the
    logo in use to be used by the program, the name of the file
    is
40
41
42     to be decided in info.csv
43
44
45 ### Files created by the program ###
46 status.csv: Contains information on status of the program.
    This csv-file uses ";" as separator and the program will
47
48     write the status at the bottom row read the
    info in the last row.
49
50     This file will contain these fields;
51     # Name of field # Datatype # Comment
52     working          : boolean   : True when active, false if
    inactive
53     done              : boolean   : True when the dxf file was
    created succesfully
54     error              : boolean   : True when an error has
    occurred
55     #                #                #
56
57 finalFileName.dxf: The final dxf file created by the
    specifications in info.csv, the name of the file is to be
    decided in
58
59     info.csv
60
61
62 errLog.txt: All expected errors will be printed to this
    file with an error message of what has caused it.
63
64 '''
65
66 import datetime
67 import sys
68 import ezdxf
69 import os
70 import csv
71 import time

```

```

63
64 '''
65 Error log
66 '''
67
68
69 def errLog(errType, errMsg, stopProg, updateStatus):
70     with open("errLog.txt", "a") as text_file:
71         __ = text_file.write(str(datetime.datetime.now
72         ())) + " | " + str(errType) + ": " + errMsg + "\n")
73     if updateStatus:
74         __ = updateStatus(_statusFileName, False, False,
75         True)
76     if stopProg:
77         sys.exit()
78     return True
79
80 Write to status.csv
81 '''
82
83
84 def updateStatus(statusFileName, working, done, error):
85     returnVal = False
86     attempts = 0
87     maxAttempts = 50
88     while (not returnVal) & (attempts < maxAttempts):
89         try:
90             with open(statusFileName, 'w', newline='') as
91             csvfile:
92                 sep = ';'
93                 statusWriter = csv.writer(csvfile,
94                 delimiter=sep, quotechar=' ', quoting=csv.QUOTE_MINIMAL)
95                 statusWriter.writerow(['sep=' + sep])
96                 statusWriter.writerow(['working', 'done',
97                 'error'])
98                 statusWriter.writerow([working, done,
99                 error])
100                 returnVal = True
101         except PermissionError:
102             errType = str(PermissionError)
103             returnVal = False
104             attempts = attempts + 1
105             __ = errLog(errType, " has occurred at " +
106             statusFileName + '. Attempt ' + str(attempts), False,

```

```

101 False)
102         time.sleep(_permWaitTime)
103     if not returnVal:
104         __ = errLog(errType, " has occurred at " +
105             statusFileName + ". Force-stops program after " + str(
106                 attempts)
107                 + " attempts.", True, False)
108     return returnVal
109
110 '''
111 Removes file from system
112 '''
113
114 def removeFile(fileName):
115     returnVal = False
116     attempts = 0
117     maxAttempts = 50
118     while (not returnVal) & (attempts < maxAttempts):
119         try:
120             returnVal = True
121             os.remove(fileName)
122         except FileNotFoundError:
123             returnVal = True
124             errType = str(FileNotFoundError)
125             __ = errLog(errType, " File " + fileName + "
126 was not found when trying to delete it.", False, False)
127         pass
128     except PermissionError:
129         returnVal = False
130         errType = str(PermissionError)
131         __ = errLog(errType,
132             " File " + fileName + " is in use
133 when trying to delete it. Close all programs using it",
134             True,
135             True)
136     if not returnVal:
137         __ = errLog(errType, " has occurred at " +
138             _statusFileName + ". Force-stops program after " + str(
139                 attempts)
140                 + " attempts.", True, False)
141     return returnVal
142
143 '''

```

```

140 Get a dxf file
141 '''
142
143
144 def getDXF(dxffFileName):
145     try:
146         temp = ezdxf.readfile(dxffFileName)
147     except FileNotFoundError:
148         __ = errLog(str(FileNotFoundError), " has occurred
149         . " + dxffFileName + " were not found", True, True)
150     except PermissionError:
151         __ = errLog(str(PermissionError), " has occurred.
152         Please close all program using " + dxffFileName
153         + " before continuing ", True, True)
154     return temp
155
156 Setup
157 '''
158 _permWaitTime = 0.1
159 _errType = "No Error"
160 _statusFileName = 'status.csv'
161 _infoFileName = "info.csv"
162 _strNameLen = 40
163 '''
164 Update status
165 '''
166 status = updateStatus(_statusFileName, True, False, False)
167 '''
168 Read info.csv
169 '''
170 with open('info.csv') as csvfile:
171     _infoReader = csv.reader(csvfile, delimiter=' ',
172     quotechar='|')
173     for row in _infoReader:
174         _info = row
175     _info = ', '.join(_info)
176     _info = _info.replace(',', ' ')
177     _info = _info.split(";")
178 '''
179 Deletes the dxf file before saving the new file, also
180 ignores exception FileNotFoundError if file does not exist
181 '''
182 _dxffFileName = str(_info[0]) # finalFileName

```

```

182 removeFile(_dxfFileName)
183 '''
184 Get template from file and create the modelspace to add
design
185 '''
186 _dxfTemplateFileName = str(_info[1]) # templateName
187 _doc = getDXF(_dxfTemplateFileName)
188 _msp = _doc.modelspace()
189 '''
190 Add NTNU Manulab logo
191 '''
192 _logoFileName = str(_info[2]) # LogoFileName
193 _xInsert = float(_info[3]) # xInsertPointLogo
194 _yInsert = float(_info[4]) # yInsertPointLogo
195 _xPixel = int(float(_info[5])) # xPixelSize
196 _yPixel = int(float(_info[6])) # yPixelSize
197 _xSize = float(_info[7]) # xSizeInmm
198 _ySize = float(_info[8]) # ySizeInmm
199 _rotLogo = float(_info[9]) # rotationLogo
200
201 _my_image_def = _doc.add_image_def(filename=_logoFileName
    , size_in_pixel=(_xPixel, _yPixel))
202 _image = _msp.add_image(image_def=_my_image_def, insert=(
    _xInsert, _yInsert), size_in_units=(_xSize, _ySize),
    rotation=_rotLogo)
203
204 '''
205 Add name text from input
206 '''
207 _textFileName = str(_info[10]) # textToInsert
208 _textStyle = str(_info[11]) # textStyle
209
210 _strName = _textFileName.replace('\n', ' ')
211 _strName = _strName[:_strNameLen]
212
213 _xLoc = float(_info[12]) # xInsertPointText
214 _yLoc = float(_info[13]) # yInsertPointText
215 _rotation = float(_info[14]) # rotationText
216 _alignment = int(float(_info[15])) # alignmentText
217 _textWidth = float(_info[16]) # textWidth
218 _textHeight = float(_info[17]) # textHeight
219
220 _mtext = _msp.add_mtext(_strName, dxfattribs={'style':
    _textStyle}).set_location((_xLoc, _yLoc), _rotation,
    _alignment)
221 _mtext.dxf.width = _textWidth

```

```
222 _mtext.dxf.char_height = _textHeight
223
224 '''
225 Save the new file
226 '''
227 _doc.saveas(_dxfFileName)
228 status = updateStatus(_statusFileName, False, True, False)
229
```